

LPN TRACKER mounting instructions

To ensure good reception of GPS data and the LoRa network, the LPN Tracker must be mounted so that the top has a clear view of the sky.

Under no circumstances may the device be mounted upside down, this would interrupt position recording and data transmission.

A good reception also grants a lateral mounting.



Glue

The LPN Tracker can be glued to the carrier with an industrial adhesive such as Sika MaxTack® Ultra or similar. Follow the instructions of the adhesive manufacturer.

1. Roughen the underside of the LPN Tracker and the mounting surface with a coarse sandpaper
2. Clean the surface on the carrier - as instructed by the adhesive manufacturer
3. Apply adhesive and join the pieces together

Screw

To screw the device tight 4 size 4M screws can be used (not included).

Other types of fastening are not recommended.