




GPS Locator

Quick Guide



Thank you

for choosing Tracker.com! In the following pages you will find key information about how to operate your GPS Locator.

The GPS Locator is preconfigured and equipped with a SIM card. It works only with the SIM card installed by Tracker.com.

Contents

GPS Locator buttons and components

First steps

Switching on/off

SIM card slot

SOS button

Mini USB port

GPS reception status display


Battery display

Mobile network reception status display

Dashboard admin.tracker.com

GPS Locator buttons and components

- (1) On/off
- (2) SIM card slot
- (3) SOS button
- (4) Mini USB port
- (5) GPS reception status display
- (6) Battery display
- (7) Mobile network reception status display (UMTS/LTE)



First steps

1. Plug the supplied power adapter into the mini USB socket **(4)** and charge the battery until the battery display **(5)** is constantly lit.
2. Hold the Mobile Locator outdoors, turn the unit on and wait approximately 2 minutes until the GPS position has been determined.
3. Check the position in the Dashboard at <https://admin.tracker.com>

The Mobile Locator is now ready and fully functional.

Switching on/off

Switching on

Push the On/Off button for a short time. The battery display (6) lights up for a short time and the mobile network display (7) begins to flash.

Switching off

Push the On/Off button for 2 seconds.

SIM card slot

The GPS Locator is preconfigured and equipped with a SIM card and will work only with this card.

SOS button

Press the SOS button for 3 seconds.

The SOS button can be assigned with the following actions:

1. sending an e-mail
2. sending a SMS (with the appropriate SMS credit)

These actions must be created in the dashboard under <https://admin.tracker.com>

Mini USB port

Here you can recharge the GPS locator using the AC adapter.

Status display for GPS reception

Flashes

Search for satellites in progress.

Lights up constantly

The GPS position is valid.

Battery display

Fast flash

Charger inserted and charging.

Constantly lit

Battery fully charged.

Slow flash

Power low alert.

Mobile network reception status display

Fast flash

Connection with the mobile network network and tracker.com is being established.

Slow flash

The unit is connected with the mobile network and tracker.com.

Locate and track at admin.tracker.com

Log on to the website <https://admin.tracker.com> with your personal login details, view your tracks and locate the device.

Manage your account, define areas (geofencing) which are to trigger actions when they are entered or left and define the actions which are triggered when the SOS button is pressed.

Tracker.ch AG

Webereistrasse 47

CH-8134 Adliswil

T: +41 43 543 43 00

F: +41 43 543 43 01

info@tracker.com

Support: +41 43 543 43 43

support@tracker.com

www.tracker.com



This equipment complies with the European
R&TTE directive. Conformity at:
<http://www.tracker.com/CE>



Gratis APP erhältlich im **AppStore** und **Android Market**
APP gratuite disponible sur les marchés **AppStore** et **Android**
APP gratuita disponibile nel mercato **AppStore** e **Android**
Free APP available in the **AppStore** and **Android market**